

East Tester®

ETX-2710 Temperature Calibrator ETX-1710 Temperature Calibrator Users Manual



Hangzhou Zhongchuang Electron Co., Ltd.

Contents

| | |
|---|----|
| 1 Basic Introduction..... | 1 |
| 1.1 Function..... | 1 |
| 1.2 Summary of Source and Measure Functions..... | 1 |
| 1.3 Terminal Description..... | 2 |
| 1.4 Key Description..... | 3 |
| 1.5 Display Screen..... | 4 |
| 2 Basic Operation..... | 5 |
| 2.1 Measure and Source..... | 5 |
| 2.2 Shutdown Mode..... | 7 |
| 2.3 Backlight Brightness Adjustment..... | 8 |
| 3 Function Usage..... | 9 |
| 3.1 DC V Measurement..... | 9 |
| 3.2 DC mV Measurement..... | 10 |
| 3.3 Resistance Measurement..... | 10 |
| 3.4 DC mV Output..... | 11 |
| 3.5 Resistance Output..... | 12 |
| 4 Temperature Measurement..... | 13 |
| 4.1 Using Thermocouple (TC)..... | 13 |
| 4.2 Using Resistance Thermometer Detector (RTD)..... | 15 |
| 5 Simulation of temperature sensor..... | 18 |
| 5.1 Simulating Thermocouples..... | 18 |
| 5.2 Application of Resistance Temperature Detector (RTD)..... | 19 |
| 6 Advanced Application..... | 21 |
| 6.1 Setting 0 % and 100 % output parameters..... | 21 |
| 6.2 Auto Ramping the Output..... | 22 |
| 6.3 Factory Reset..... | 22 |
| 7 Power..... | 23 |
| 7.1 Charge..... | 23 |
| 8 Specifications..... | 24 |
| 8.1 DC Voltage Measurement..... | 24 |

| | |
|---------------------------------|----|
| 8.2 DC Voltage Source..... | 24 |
| 8.3 Resistance Measurement..... | 25 |
| 8.4 Resistance Output..... | 25 |
| 8.5 Temperature, TC..... | 26 |
| 8.6 Temperature, RTD..... | 27 |
| 9 Product Accessories..... | 28 |
| 9.1 Standard Accessories..... | 28 |
| 9.2 Optional accessories..... | 28 |
| 10 Warning..... | 29 |

1 Basic Introduction

1.1 Function

- It allows you to measure DC V, DC mV, resistance ,TC and RTD.
- Outputs resistance, simulation of TC and RTD.
- Thermocouple(TC) measurement provides cold-junction compensation.
- Manual stepping, automatic stepping, 0~100% phase step and ramp output.
- Super-strong protection : The waterproof grade is IP67. Automatic protection against the signal terminals connect to the 220V.
- Support for PC communication

1.2 Summary of Source and Measure Functions

| Function | Measure | Source |
|------------|--|----------------------------|
| DC V | 0~30V | Not available |
| DC mV | 0~120mV | 0mV~100mV |
| Resistance | 0~3200Ω | 0~3200Ω |
| RTD | Pt100, Pt1000, Cu50, Cu100 | Pt100, Pt1000, Cu50, Cu100 |
| TC | E,J,K,T,B,R,S,N | E,J,K,T,B,R,S,N |
| Others | Stepping output, ramp, phase step output, user-defined range | |

1.3 Terminal Description




Figure 1.3-1

| No. | Name | Description |
|-----|--------------------------------------|--|
| ① | Communication and charging connector | Connect power adaptor to charge batteries or connect the calibrator to the computer. |
| ② | 3W and 4W terminal | 3-wire and 4-wire electric and thermal resistance measurement terminal. |
| ③ | COM Public terminal | All measurement and output public terminal. |
| ④ | V, mV, Ω, TC and RTD terminal | Voltage and DC mV, 2-wire resistance, thermal-electric and resistance measurement as well as DC mV, resistance, thermocouple and thermal-resistance output terminal. |
| ⑤ | 4W+ terminal | Resistance and thermal resistance 4-wire measurement terminal. |

1.4 Key Description




Figure 1.4-1

| No. | | Description |
|-----|--|--|
| ① | | Turns the power on or off |
| ② | | Selects the measurement mode |
| ③ | | Selects output and analog transmitter mode. |
| ④ | | Enables backlight switch display during start, enters backlight brightness control mode. |
| ⑤ | | Selects thermal resistance mode |
| ⑥ | | Sets and saves calibrator parameters setting |

| | | |
|------|--------|--|
| ⑦ | RECALL | Recovers factory default setting |
| ⑧ | ▲▼◀▶ | Sets manual output |
| ⑨ | ΛΜΓ | Cycles through: Λ slow repeating 0%-100%-0% ramp Μ Fast repeating 0 % - 100 % - 0 % ramp Γ Repeating 0 % - 100 % - 0 % ramp in 25 % steps |
| ⑩ | 0% | Set output by 0% of span, Press and hold to store the source value as the 0 % value |
| (11) | ▼ 25% | Decrements output by 25% of span. |
| (12) | ▲ 25% | Increments output by 25% of span. |
| (13) | 100% | Sets output by 100% of span, Press and hold to store the source value as the 100 % value. |
| (14) | V mV Ω | Sets voltage, DC mV and resistance mode |
| (15) | TC | Selects thermo-couple mode |

1.5 Display Screen




Figure 1.5-1

2 Basic Operation

2.1 Measure and Source

This section acquaints you with some basic operations of ETX-2010/ ETX-1810.

Proceed as follows:

1. The connection of the calibrator as shown in Figure 2.1-1.





Figure 2.1-1

2. Press  more than 2 seconds to turn on the calibrator. The calibrator checks itself, including check on internal circuit and LCD, during which, LCD displays all contents for 1s as shown in Figure 2.1-2:




Figure 2.1-2

3. Then the product model (2010) and automatic shutdown time (30 min) will be displayed for 2 seconds as shown in Figure 2.1-3.




Figure 2.1-3

4. Then the default interface of boot will be displayed as shown in Figure 2.1-4:




Figure 2.1-4

5. Press , switch to the voltage mode. Switching is not required for this series after starting-up.
6. Press to enter into output mode selection
7. Press to enter into DC mV output mode as shown in Figure 2.1-5.




Figure 2.1-5

8. Press and to increase or decrease 1 of the horizontal line position (the number will be based on automatic stepping without change of horizontal line position); press or to change the position of horizontal line.
9. Press until the buzzer works and to enter 0mV as 0% value.
10. Likewise, press to increase output value to be 100mV, and then press until the buzzer works and enter 100mV as 100% value.
11. Press or to make output increase or decrease within the span of 0% to 100% based on 25% advance amplitude. The screen will display as shown in Figure 2.1-6.




Figure 2.1-6

2.2 Shutdown Mode

The calibrator comes with the shutdown mode enabled for a time duration set to 30 minutes (displayed for about 2 seconds when the calibrator is initially turned on). When the shutdown mode is enabled, the calibrator will automatically shutdown after the time duration has elapsed from the time the last key was pressed. To disable the










shutdown mode, press  and  simultaneously. To enable the mode, press  and  simultaneously. To adjust the time duration, press  and  simultaneously, the screen will display as shown in Figure 2.2-1, then press  and/or  to adjust the time between 1 and 30 minutes and then press  to store the new time duration (Without pressing any key for 5 seconds, the calibrator will quit from the adjustment automatically).



Figure 2.2-1

2.3 Backlight Brightness Adjustment

To adjust the brightness of backlight, proceed as follows:







1. Please press  and  simultaneously until the buzzer work, then the screen will display as shown in Figure 2.3-1:



Figure 2.3-1

2. Press  and  to adjust the brightness of backlight.
3. Press  to save brightness level,  will appear and then the calibrator will enter into the work mode (Without pressing key for 5 seconds, the calibrator will exit from the adjustment automatically).

3 Function Usage

3.1 DC V Measurement

The default function after turn on is DC V measurement. If it is required, press $\boxed{\text{V mV } \Omega}$ to re-select the voltage measurement (the display unit is V). Please connect the lines after all functions are selected. The connection mode and interface are shown in Figure 3.1-1:




Figure 3.1-1

3.2 DC mV Measurement

Press $\boxed{\text{V mV } \Omega}$ to re-select the DC mV function (the display unit is DC mV), the connection mode is same to that of voltage measurement. The screen will display as shown in Figure 3.2-1.




Figure 3.2-1

3.3 Resistance Measurement

Press $\boxed{\text{V mV } \Omega}$ to reselect the DC mV measurement function (Display unit is Ω)




Figure 3.3-1

The Over Span Under Open Circuit

Resistance measurement supports the connection type of two-wire system, three-wire system and four-wire system. The calibrator can be switched to three-wire system or four-wire system according to actual connecting type. The respective connecting types are listed in Figure 3.3-2: Press \triangle and ∇ to select the connection mode forcibly.




Figure 3.3-2

Press or to force the calibrator to adopt two-wire system, three-wire system or four-wire system. Afterwards, the calibrator will not detect connecting type automatically unless you quit the mode of resistance measurement and re-enter.

3.4 DC mV Output

Press and to select DC mV output function, the connection mode is same to that of voltage measurement. The screen will display as shown in Figure 3.4-1.




Figure 3.4-1

3.5 Resistance Output

Press **OUTPUT** and **V mV Ω** to select the resistance output function, the connection mode is same to that of voltage measurement.




Figure 3.5-1

Lo indicates the undersize of exciting current, meanwhile, the main value flashes

Press **V mV Ω** to select resistance output at 3200 Ω level.




Figure 3.5-2

Hi indicates the oversize of exciting current, meanwhile, the main value flashes

4 Temperature Measurement

4.1 Using Thermocouple (TC)

The calibrator supports eleven standard thermocouples, including J, K, T, E, R, S, B, L, U and N. Lower table summarizes the ranges and characteristics of the supported thermocouples

| Graduation | Positive lead material | Positive wire (H) color | | Negative lead material | Specified span℃ |
|------------|------------------------|-------------------------|--------|--------------------------|-----------------|
| | | ANSI* | IEC** | | |
| E | Chrome-nickel | Mauve | Purple | Constantan | -200～950 |
| N | Nickel-chrome-silicon | Orange | Pink | Nickel-silicon-magnesium | -200～1300 |
| J | Iron | White | Black | Constantan | -200～1200 |
| K | Chrome-nickel | Yellow | Green | Alumel | -200～1370 |
| T | Copper | Blue | Brown | Constantan | -200～400 |
| B | Platinum (30% rhodium) | Grey | | Platinum (6% rhodium) | 600～1800 |
| R | Platinum (13% rhodium) | Black | Orange | Platinum | -20～1750 |
| S | Platinum (10% rhodium) | Black | Orange | Platinum | -20～1750 |

* Negative conductor (L) regulated as American National Standard (ANSI) is always red.
 **Negative conductor (L) regulated as International Electro-technical Commission (L) is always white.

To measure temperature using thermocouple, the following steps shall be followed:

1. Connect the thermocouple to the calibrator as shown in Figure 4.1-1:




Figure 4.1-1

Attention:

Under different calibrator-thermocouple temperature environment, you shall wait for one minute to stabilize the plug temperature after connecting TC to input & output wiring.

2. Press to select measurement mode.
3. Press to display thermocouple reading as shown in Figure 4.1-2. If necessary, pressing continuously to select appropriate thermocouple type.



Figure 4.1-2

4. Press to display the DC mV value reading as shown in Figure 4.1-3. The DC mV value continue to display for 3s and then automatically return to the original display .



Figure 4.1-3

There are two kinds of cold end temperature compensation for thermocouple measurement, automatic compensation directly using machine internal cold end temperature compensation and manual compensation through the key to set the cold end temperature compensation by the user.

4.1.1 Automatic compensation

First entered the thermocouple measurement mode, the default of the cold end temperature compensation is automatic compensation reading as shown in Figure 4.1.1-1. The **Auto** sign represents that the current cold end temperature compensation is automatic compensation. If you need further view current automatic cold end temperature compensation value, you have to operation **RECALL** key. Reading as shown in Figure 4.1.1-1, after press **RECALL** key, the **Auto** sign is replaced for current automatic cold end temperature compensation value as **20.3**. The value **20.3** continue to display for 2s and then automatically return to the **Auto** sign.



Figure 4.1.1-1

4.1.2 Manual compensation

Manual compensation through the key to set the cold end temperature compensation by the user, the following steps shall be followed:







1. Press  key to enter the set mode, reading as shown in Figure 4.1.2-1, the appear of **STORE** sign shows that entering the setup mode, the assistant value **23.0** means the value of manual compensation.



Figure 4.1.2-1

2. If you need to adjust the manual compensation value, press     keys to adjust.
3. Press  key to save the value of manual compensation and exit from the setup mode at the same time, reading as shown in Figure 4.1.2-2.




Figure 4.1.2-2

4. If necessary, press  key return to automatic compensation.

4.2 Using Resistance Thermometer Detector (RTD)

The calibrator accepts Pt100, Pt1000, Cu50 and Cu100, etc. The calibrator accepts RTD measurements inputs in two-, three-, or four-wire connections, with the three-wire connection the most common. A four-wire configuration provides the highest measurement precision, and two-wire provides the lowest measurement precision.

To measure temperature using an RTD input, proceed as follows:

1. Press to select mode.
2. Press for the RTD display. Then the screen will display as shown in Figure 4.2-1. If desired, continue pressing this key to select the desired RTD type.
3. Connect RTD to the corresponding port according to the connecting type of 'resistance measurement'.




Figure 4.2-1

5 Simulation of temperature sensor

5.1 Simulating Thermocouples

Connect calibrator input/output terminal to the instrument to be tested using thermocouple. The connecting diagram is shown below, Proceed as follows to simulate a thermocouple:

1. Connect thermocouple to the TC input/output plughole of calibrator as shown in Figure 5.1-1.
2. If necessary, press **OUTPUT** to select output mode.
3. Press **TC** to select thermocouple function. If necessary, continue pressing the key to select thermocouple graduation.
4. Press **▲** or **▼** to select temperature. Press **◀** or **▶** to select digit.




Figure 5.1-1

5. Press **OUTPUT** to display the DC mV value, which continue to display for 3s and

then automatically return to the original display .

Simulating Thermocouples also have two kinds of cold end temperature compensation, automatic and manual compensation. The method of operation is same to using thermocouple, please refer to 4.1 section for specific operation.

5.2 Application of Resistance Temperature Detector (RTD)

Connect the calibrator and the instrument to be tested according to the Figure 5.2-1.

Simulation of RTD should be based on the following steps:

1. If necessary, press **OUTPUT** to select **OUTPUT** mode.
2. Press **RTD** to select RTD graduation.
3. Press Δ or ∇ to select temperature. Press \leftarrow or \rightarrow to select digit.




Figure 5.2-1






Three-wire (3 W) and four-wire (4 W) terminals are just for measurement, not output simulation. The calibrator can simulate a two-wire RTD output in the front panel. To be connected to a three-wire or four-wire transducer, use folding cable to provide extra wiring.





6 Advanced Application

6.1 Setting 0 % and 100 % output parameters

As for stepping operation and percentage display, 0% and 100% should be set before using. Some gear values have been set when delivered from the factory and set values are illustrated below:


| Output Function | 0% value | 100% value |
|----------------------|----------|------------|
| DC mV | 0.00 mV | 100.00 mV |
| Resistance 400Ω | 0.00 Ω | 400.00 Ω |
| Resistance 3200Ω | 0.0 Ω | 3200.0 Ω |
| Thermocouple J type | 0.0 °C | 1000.0 °C |
| Thermocouple K type | 0.0 °C | 1000.0 °C |
| Thermocouple T type | 0.0 °C | 400.0 °C |
| Thermocouple E type | 0.0 °C | 800.0 °C |
| Thermocouple R type | 0 °C | 1500 °C |
| Thermocouple S type | 0 °C | 1500 °C |
| Thermocouple B model | 600 °C | 1800 °C |
| Thermocouple N model | 0.0 °C | 1000.0 °C |
| Pt100 | 0.0 °C | 500.0 °C |
| Pt1000 | 0.0 °C | 400.0 °C |
| Cu50 | 0.0 °C | 150.0 °C |
| Cu100 | 0.0 °C | 150.0 °C |




The default set values may not meet your requirements, so you can reset them. Then you can display the percentage with stepping or ramp output as well as display the percentage. Adjust the output value with keys   , press and hold  or  for a long time until the buzzer sends a “Ticking” sound to define the new 0% or 100% values. The new defined span value is saved in the calibrator storage automatically and remains effective after restart. The flowing operations are available with the setting:

- Press  or  for manual steeping (increase or decrease) output based on 25% increment.
- Press  or  instantly to make output jump within the span of 0% to 100%.

6.2 Auto Ramping the Output

Automatic ramping gives you the ability to continuously apply a varying stimulus from the calibrator to a transmitter, while your hands remain free to test the response of the transmitter.

When you press , the calibrator produces a continuously repeating 0 % - 100 % - 0 % ramp in your choice of three ramp waveforms:


-  0%-100%-0% 40-second smooth ramp
-  0%-100%-0% 15-second smooth ramp
-  0%-100%-0% Stair-step ramp in 25 % steps, pausing 5 seconds at each step.

Exit the slop output function, please press any key.

6.3 Factory Reset

Factory reset consists of the following items:

- The working status recovers to the voltage measurement.
- Automatic shutdown time is reset to be 30 min, which is effective.
- LCD backlight brightness is set to be 60%.
- Output span is recovered to be factory default.





Start the calibrator and press  until the buzzer works, and the recovery of factory default will enter working mode when the recovery is completed.

7 Power

The calibrator needs 6 disposable LR03 model (size 7) alkaline batteries or 6 R03 model (size 7) nickel-metal hydride batteries (or nickel-cadmium batteries). The longest service life of alkaline batteries can reach 50 hours.

A 12V/1A power adaptor is used for charging and providing working power for the calibrator.

7.1 Charge

When the battery indicator is pointed at , the remaining electric quantity is less than 20%. Charge is necessary for normal operation of the calibrator. The LCD backlight will start operation and the  will display on the screen when the power adaptor is used. If the battery indicator  flashes, the calibrator will be in the charging process, after which the battery indicator  will stop flashing.

The calibrator will stop charge automatically in case of the following circumstances:

- Disposable batteries are used.
- Electric quantity is enough.

8 Specifications

Specifications are based on a one year calibration cycle and apply from +18°C to +28 °C unless stated otherwise. All specifications assume a 10 minute warmup period.

8.1 DC Voltage Measurement

| Range | Maximum measurement range | Resolution | Accuracy (% of reading + Counts) | |
|--|---------------------------|------------|----------------------------------|----------|
| | | | ETX-1810 | ETX-2010 |
| 30V | 0V~31V | 0.001V | 0.05+2 | 0.02+2 |
| 100mV | -15mV~80mV | 0.001mV | 0.05+20 | 0.02+20 |
| | 80mV~125mV | 0.01mV | 0.05+2 | 0.02+2 |
| -10 °C~18 °C, +28 °C~55 °C temperature coefficient,±0.005%FS/ °C. Input resistance: >1MΩ. | | | | |

8.2 DC Voltage Source

| Range | Maximum output range | Resolution | Accuracy (% of reading + Counts) | |
|--|----------------------|------------|----------------------------------|----------|
| | | | ETX-1810 | ETX-2010 |
| 100mV | -15mV~99.999mV | 0.001mV | 0.05+20 | 0.02+20 |
| | 100mV~125mV | 0.01mV | 0.05+2 | 0.02+2 |
| -10 °C~18 °C, +28 °C~55 °C temperature coefficient,±0.005%FS/ °C. Maximum load: 1mA or 1kΩ (It should be based on the lower load.) | | | | |

8.3 Resistance Measurement

| Range | Maximum measurement range | Resolution | Accuracy (Ω) | | | |
|--|-----------------------------|---------------|-----------------------|--------|----------------|--------|
| | | | ETX-1810 | | ETX-2010 | |
| | | | 2-wire, 3-wire | 4-wire | 2-wire, 3-wire | 4-wire |
| 400 Ω | 0~440 Ω | 0.01 Ω | 0.25 | 0.15 | 0.15 | 0.10 |
| 3200 Ω | 420 Ω ~3600 Ω | 0.1 Ω | 1.5 | 1.0 | 1.0 | 0.5 |
| <p>-10 $^{\circ}\text{C}$~18 $^{\circ}\text{C}$, +28 $^{\circ}\text{C}$~55 $^{\circ}\text{C}$ temperature coefficient, $\pm 0.005\% \text{FS}/^{\circ}\text{C}$. Exciting current during measurement: 400Ω: 1.0mA$\pm 10\%$; 3200Ω: 0.2mA$\pm 10\%$; Two-wire: Conductor resistance is excluded from errors. Three-wire: Matching test line should be used. The total resistance of conductor should not be larger than 25Ω.</p> | | | | | | |

8.4 Resistance Output

| Range | Maximum output range | Resolution | External exciting current | Accuracy (Ω) | |
|---|----------------------|---------------|---------------------------|-----------------------|----------|
| | | | | ETX-1810 | ETX-2010 |
| 400 Ω | 0~440 Ω | 0.01 Ω | 0.4mA~4.0mA | 0.25 | 0.15 |
| 3200 Ω | 400~3600 Ω | 0.1 Ω | 0.1mA~0.5mA | 1.0 | 0.50 |
| <p>-10 $^{\circ}\text{C}$~18 $^{\circ}\text{C}$, +28 $^{\circ}\text{C}$~55 $^{\circ}\text{C}$ temperature coefficient, $\pm 0.005\% \text{FS}/^{\circ}\text{C}$.</p> | | | | | |

8.5 Temperature, TC

| Graduation | Range | Resolution | Accuracy (Ω) | |
|---|--|------------|-----------------------|-------------------------|
| | | | ETX-1810 | ETX-2010 |
| J | -200°C ~ 0°C 0°C ~ 1200°C | 0.1°C | 1.5°C 1.0°C | 1.0°C 0.7°C |
| K | -200°C ~ 0°C 0°C ~ 1370°C | 0.1°C | 1.8°C 1.2°C | 1.2°C 0.8°C |
| T | -200°C ~ 0°C 0°C ~ 400°C | 0.1°C | 1.8°C 1.2°C | 1.2°C 0.8°C |
| E | -200°C ~ 0°C 0°C ~ 950°C | 0.1°C | 1.5°C 1.0°C | 0.9°C 0.7°C |
| R | -20°C ~ 0°C 0°C ~ 500°C 500°C ~ 1750°C | 0.1°C | 4°C 2.5°C 2°C | 2.5°C 1.8°C 1.4°C |
| S | -20°C ~ 0°C 0°C ~ 500°C 500°C ~ 1750°C | 0.1°C | 4°C 2.5°C 2°C | 2.5°C 1.8°C 1.5°C |
| B | 600°C ~ 800°C 800°C ~ 1000°C 1000°C ~ 1800°C | 0.1°C | 3.5°C 2.5°C 2°C | 2.2°C 1.8°C 1.4°C |
| N | -200°C ~ 0°C 0°C ~ 1300°C | 0.1°C | 2.0°C 1.2°C | 1.5°C 0.9°C |
| <i>Errors of cold-junction compensation are not included in the table. Accuracy of cold-junction compensation: 1.5 °C</i> | | | | |

8.6 Temperature, RTD

| Graduation | Range | Resolution | Accuracy (°C) | | | | | |
|---|-------------------|------------|------------------|--------|--------|------------------|--------|--------|
| | | | ETX-1810 | | | ETX-2010 | | |
| | | | 2-wire 3-wire | 4-wire | Output | 2-wire 3-wire | 4-wire | Output |
| Pt100 | -200°C ~ 850°C | 0.1°C | 0.7 | 0.4 | 0.7 | 0.4 | 0.3 | 0.3 |
| Pt1000 | -200°C ~ 650°C | | 0.4 | 0.3 | 0.3 | 0.3 | 0.15 | 0.15 |
| Cu50 | -50°C ~150°C | | 1.2 | 0.8 | 0.8 | 0.8 | 0.5 | 0.5 |
| Cu100 | -50°C ~150°C | | 0.7 | 0.4 | 0.4 | 0.4 | 0.25 | 0.25 |
| As for exciting current during measurement, please refer to resistance measurement function. | | | | | | | | |
| As for allowable external exciting current during output, please refer to resistance output function. | | | | | | | | |
| 2-wire: Does not include lead resistance. | | | | | | | | |
| 3-wire: Assumes matched leads with a total resistance not exceeding 25Ω. | | | | | | | | |

9 Product Accessories

9.1 Standard Accessories

A set of ETX-2010/ETX-1810 calibrator also includes the following items:

- hard spot test leads (one set)
- alligator clip (one set)
- one 12V/1A power adaptor
- ETX-2010/ETX-1810 users manual




Figure 9.1-1

9.2 Optional accessories

- 6 R03-model rechargeable batteries
- 1 Metal Box
- Communication line

10 Warning

To avoid possible electric shock or personal injury:

- Test a given voltage to confirm its normal operation before using.
- Please follow all the safety operation standards.
- Select correct function and range gear according to measurement requirements.
- Confirm the closing of battery door before calibrator application.
- Remove the test line of calibrator before opening the battery door.
- Check whether damaged or exposed metal exists in the test line and whether the test line has been conducted. Replace the damaged test line before using.
- Fingers should not touch the metal contact when the detector is used. Fingers should be behind the finger-protecting device.
- Connect the common line and then electric test line. As for wire removal, electric test line should be first removed.
- Don't use the calibrator in case of abnormal operation. Calibrator should be repaired because it may have been damaged.
- Don't use the calibrator near explosive gases.
- Remove the test line before changing measurement or output function.
- 6 LR03 (7 size) alkaline batteries or R03 nickel-metal hydride batteries (or nickel-cadmium batteries) should be used in the calibrator and the battery should be placed inside the meter housing.
- Replace or charge the battery when the screen displays low pressure of battery, to avoid reading error and possible electric shock or personal injury.

Hangzhou Zhongchuang Electron Co.,Ltd.

Phone: 0086-571-56770221

Fax: 0086-571-56861355

Website: [Http://www.east-tester.com](http://www.east-tester.com)

E-mail: sales@east-tester.com

Zip Code: 310015

Address: No.3, Kangle Road, Gongshu District, Hangzhou, Zhejiang, China